



INSTALLATION GUIDELINES

TWO PIECE SNAP ON COPPER PIPE FLASHING PANEL
CUT OUT SIZE ½" TO 2"
PART # P-2PS

PANEL INSTALLATION

- STEP 1) Cut panel scores to size of pipe.
- STEP 2) Place bottom panel under pipe.
- STEP 3) Snap top panel to bottom panel (over pipe).
- STEP 4) **MUST** caulk pipe to panel for a weatherproof seal.

Installation of *QUICKFLASH* panel is now complete.

LATHING INSTRUCTIONS

- STEP 1) Place building paper (weather resistive barrier) up behind bottom of panel to bottom of pipe.
- STEP 2) Place 2ND layer of building paper over top of panel to bottom front edge, or further down.

WARNING

ALL *QUICKFLASH* PRODUCTS MUST BE INSTALLED BY A PROPERLY LICENSED CONTRACTOR, IN STRICT ACCORDANCE WITH MANUFACTURER'S RECOMMENDATIONS, ALL APPLICABLE BUILDING AND SAFETY CODES, ANY EVALUATION REPORTS ISSUED BY THE INTERNATIONAL CONFERENCE OF BUILDING OFFICIALS, APPLICABLE PLANS AND SPECIFICATIONS, AND ANY LOCAL LAWS OR REGULATIONS.