



INSTALLATION GUIDELINES

Plumbing Pipe Flashing Panel (One Piece)

Select *QUICKFLASH* P-series panel engineered for specific pipe sizes to be used in your application. Model number, description of pipe type and pipe diameter fit is available on *QUICKFLASH* brochure.

After selecting proper *QUICKFLASH* panel, push panel over pipe with label facing out (away from house) for a no caulk weatherproof seal.

The *QUICKFLASH* panel forms a weatherproof seal around pipe.

Nailing of panels is not required and is optional. If contractor desires to nail, do so with a corrosion resistant nail, at **TOP** panel only.

Installation of *QUICKFLASH* panel is now complete.

LATHING INSTRUCTIONS

STEP 1) Place building paper (weather resistive barrier) up behind bottom of panel to bottom of plumbing protrusion.

STEP 2) Place 2nd layer of building paper over top of panel to bottom front edge, or further down.

WARNING

COPPER PIPES SHOULD BE HEAT SWEATED, PRIOR TO THE FLASHING PANEL INSTALLATION TO AVOID LOSS OF THE INTEGRITY OF RUBBER SEAL.

ALL *QUICKFLASH* PRODUCTS MUST BE INSTALLED BY A PROPERLY LICENSED CONTRACTOR, IN STRICT ACCORDANCE WITH MANUFACTURER'S RECOMMENDATIONS, ALL APPLICABLE BUILDING AND SAFETY CODES, ANY EVALUATION REPORTS ISSUED BY THE INTERNATIONAL CONFERENCE OF BUILDING OFFICIALS, APPLICABLE PLANS AND SPECIFICATIONS, AND ANY LOCAL LAWS OR REGULATIONS.

4129 Wagon Trail Ave., Las Vegas, NV 89118
Phone 702.614.6100 Fax 702.614.4090